

Rev B2, Page 1/10

FEATURES

- Differential sine and cosine output signals
- Magnetic rotation speed up to 20,000 rpm
- Low output offset supporting 10bit interpolation accuracy
- Reasonable alignment tolerance
- Automatic gain control for 0.8 to 1.2 Vpp output signal
- Loss of magnet detection and error message indication
- ◆ Extended temperature range of -40 to +125 °C

APPLICATIONS

- Absolute angular encoder
- Brushless motors
- Motor feedback
- Rotational speed control

PACKAGES







DESCRIPTION

The iC-MHA is a position sensor with integrated Hall sensors for scanning a permanent magnet. The signal conditioning unit generates constant-amplitude sine and cosine voltages that can be used for angle calculation. Sine and cosine signals are available via line driver outputs (100 Ω load)

PACKAGING INFORMATION QFN28 5 x5 mm² to JEDEC MO-220-VHHD-1

PIN CONFIGURATION QFN28 5 x 5mm²



PIN FUNCTIONS				
No.	Name	Function		
2 3 4,13 10 11 18 19 25 26	NERR VPA VNA1, VNA2 PCOUT NCOUT VND VPD NSOUT PSOUT TP	Error Output (active low) +5 V Analog Supply Voltage Analog Ground Positive Cosine Output Negative Cosine Output Digital Ground +5 V Digital Supply Voltage Negative Sine Output Positive Sine Output Thermal-Pad		
8,9 14 23,24 27,28	nc nc nc nc	not connected not connected not connected not connected		
1 5 6 7 12 15 16 17 20 21 22	PT1 PT5 PT6 PT7 PT12 PT15 PT16 PT17 PT20 PT21 PT22	Pins for device test and factory calibration: connect to VND connect to VPD do not connect (leave open) do not connect (leave open)		

The *Thermal Pad* is to be connected to VNA1, VNA2 and heat sink area. Orientation of package marking is subject to alteration (© MHA code etc.).



Rev B2, Page 3/10

PACKAGE DIMENSIONS

All dimensions given in mm.



All dimensions given in mm. Tolerances of form and position according to JEDEC MO-220.

Tolerance of sensor pattern: ±0.10mm / ±1° (with respect to center of backside pad). dra_gfn28-5x5-2_mh8_pack_1, 10:1



Rev B2, Page 4/10

ABSOLUTE MAXIMUM RATINGS

These ratings do not imply operating conditions; functional operation is not guaranteed. Beyond these ratings device damage may occur.

ltem	Symbol	Parameter	Conditions			Unit
No.				Min.	Max.	
G001	V()	Voltages at VPA, VPD		-0.3	6	V
G002	V(PT12)	Voltage at PT12		-0.3	8	V
G003	V()	Voltages at NERR, PSOUT, NSOUT, PCOUT, NCOUT, PT1, PT5, PT6, PT7, PT15, PT16, PT17, PT20, PT21, PT22		-0.3	6	V
G004	I()	Current in VPA		-10	20	mA
G005	I()	Current in VPD		-20	200	mA
G006	I()	Current in NERR, PT1, PT5, PT6, PT7, PT15, PT16, PT17, PT20, PT21, PT22		-10	10	mA
G007	I()	Current in PSOUT, NSOUT, PCOUT, NCOUT		-50	50	mA
G008	Vd()	ESD Susceptibility at all pins	HBM 100 pF discharged through 1.5 k Ω		2	kV
G009	Tj	Junction Temperature		-40	150	°C
G010	Ts	Storage Temperature		-40	150	°C

THERMAL DATA

Operating conditions: VPA = VPD = 5 V ± 10 %

Item	Symbol	Parameter	Conditions				Unit
No.	-			Min.	Тур.	Max.	
T01	Та	Operating Ambient Temperature Range		-40		125	°C
T02	Rthja	Thermal Resistance Chip to Ambient	surface mounted to PCB, thermal pad linked to cooling area of approx. 2 cm ²		40		K/W



Rev B2, Page 5/10

ELECTRICAL CHARACTERISTICS

Operating conditions: VPA = VPD = 5 V \pm 10 %, VNA = VND, Tj = -40...125 °C, 4 mm NdFeB magnet, unless otherwise noted

ltem No.	Symbol	Parameter	Conditions	Min.	Typ.	Max.	Unit
General							
001	V(VPA), V(VPD)	Permissible Supply Voltage		4.5		5.5	V
002	I(VPA)	Supply Current in VPA		3		12	mA
003	I(VPD)	Supply Current in VPD	without load	2		18	mA
004	Vc()hi	Clamp Voltage hi at NERR	Vc()hi = V() - VPD, I() = 1 mA	0.4		1.5	V
005	Vc()lo	Clamp Voltage lo at NERR	I() = -1 mA	-1.5		-0.3	V
Hall S	ensors		·				
101	Hext	Operating Magnetic Field Strength	at surface of chip	20		100	kA/m
102	fmag	Operating Magnetic Field Fre- quency Rotating Speed of Magnet				330 20 000	Hz rpm
103	dsens	Diameter Of Hall Sensor Array			2		mm
104	xdis	Max. Magnet Axis Displacement vs. Center Of Hall Sensor Array				0.2	mm
Signa	Level Cont	rol					
201	Vpp	Differential Peak-To-Peak Output Amplitude	Vpp = Vpk(Px) - Vpk(Nx), see Fig. 5	0.8		1.2	Vpp
202	∆Vpk()	Amplitude Ratio Error	Vpk(PSIN-NSIN) vs. Vpk(PCOS-NCOS)		1		%
203	ΔVos()	Offset Error			0.2		%
204	ton	Controller Settling Time	to ±10% of final amplitude			300	μs
205	Vt()lo	MINERR Amplitude Error Thresh- old	see 201	0.3		0.7	Vpp
206	Vt()hi	MAXERR Amplitude Error Threshold	see 201	1.25		1.45	Vpp
Error Message Output NERR							
905	lpu()	Pull-up Current Source	V(NERR) = 0VPD - 1 V	-800	-300	-80	μA
906	lsc()lo	Short-Circuit Current Lo	$V(NERR) = V(VPD), Tj = 25 \degree C$		50	80	mA
907	tf()hilo	Decay Time	CL = 50 pF			60	ns
Analog Output Line Driver PSOUT, NSOUT, PCOUT, NCOUT							
Q01	Vpk()	Permissible Max. Output Signal Amplitude	RL = 50 Ω vs. VDD / 2, see Fig. 1			300	mV
Q02	Vos()	Output Offset Voltage			±1		mV
Q03	fc()	Output Cut-off Frequency	CL = 250 pF	10			kHz
Q04	lsc()hi, lo	Output Short-circuit Current	pin shorten to VPD or VND	10		50	mA



Rev B2, Page 6/10



Figure 1: Definition of output signal amplitude



Rev B2, Page 7/10

SENSOR PRINCIPLE



Figure 2: Sensor principle

In conjunction with a rotating permanent magnet, the iC-MHA module can be used to create a complete encoder system. A diametrically magnetized, cylindrical permanent magnet made of neodymium iron boron (NdFeB) or samarium cobalt (SmCo) generates optimum sensor signals. The diameter of the magnet should be in the range of 3 to 6 mm.

The iC-MHA has four Hall sensors adapted for angle determination and to convert the magnetic field into a measurable Hall voltage. Only the z-component of the magnetic field is evaluated, whereby the field lines pass through two opposing Hall sensors in the opposite direction. Figure 2 shows an example of field vectors. The arrangement of the Hall sensors is selected so that the mounting of the magnets relative to iC-MHA is extremely tolerant. Two Hall sensors combined provide a differential Hall signal. When the magnet is rotated around the longitudinal axis, sine and cosine output voltages are produced which can be used to determine angles.

Position of the Hall sensors and the analog sensor signal

The Hall sensors are placed in the center of the QFN28 package at 90° to one another and arranged in a circle with a diameter of 2 mm as shown in Figure 3.



Figure 3: Position of the Hall sensors

When a magnetic south pole comes close to the surface of the package the resulting magnetic field has a positive component in the +z direction (i.e. from the top of the package) and the individual Hall sensors each generate their own positive signal voltage.

In order to calculate the angle position of a diametrically polarized magnet placed above the device a difference in signal is formed between opposite pairs of Hall sensors, resulting in the sine being $V_{SIN} = V_{PSIN} - V_{NSIN}$ and the cosine $V_{COS} = V_{PCOS} - V_{NCOS}$. The zero angle position of the magnet is marked by the resulting cosine voltage value being at a maximum and the sine voltage value at zero.

This is the case when the south pole of the magnet is exactly above the PCOS sensor and the north pole is above sensor NCOS, as shown in Figure 4. Sensors PSIN and NSIN are placed along the pole boundary so that neither generate a Hall signal.

When the magnet is rotated counterclockwise the poles then also cover the PSIN and NSIN sensors, resulting in the sine and cosine signals shown in Figure 5 being produced.



Rev B2, Page 8/10



Figure 4: Zero position of the magnet



Figure 5: Pattern of the analog sensor signals with the angle of rotation



Rev B2, Page 9/10

REVISION HISTORY

Rel	Rel.Date	Chapter	Modification	Page
A1	13-05-08		first release for web upload	
Rel	Rel.Date	Chapter	Modification	Page
B1	14-05-13	PACKAGING INFORMATION	recommended connection of pins 15, 16, 17, 20, 21, 22 changed to "do not connect"	2
		PACKAGING INFORMATION	package dimension drawing now includes hall sensor location and position tolerance	3
		ABSOLUTE MAXIMUM RATINGS	G002, G003 and G006: descrption extended for all PT-Pins G007: added for analog output pins PSOUT, NSOUT, PCOUT, NCOUT G009, G010: max. values increased to 150°C	4
		ELECTRICAL CHARACTERISTICS	former items 105 to 107 omitted, as mechanical tolerances are given in package dimensions on page 3 $$	5
		SENSOR PRINCIPLE	color style of Figure 2 changed	7
		Position of the Hall sensors and the analog sensor signal	color style of Figure 4 and 5 changed	8
		-		
Rel	Rel.Date	Chapter	Modification	Page
B2	14-05-15		revision history added (this chapter)	9

iC-Haus expressly reserves the right to change its products and/or specifications. An info letter gives details as to any amendments and additions made to the relevant current specifications on our internet website www.ichaus.de/infoletter; this letter is generated automatically and shall be sent to registered users by email.

Copying - even as an excerpt - is only permitted with iC-Haus' approval in writing and precise reference to source.

iC-Haus does not warrant the accuracy, completeness or timeliness of the specification and does not assume liability for any errors or omissions in these materials.

The data specified is intended solely for the purpose of product description. No representations or warranties, either express or implied, of merchantability, fitness for a particular purpose or of any other nature are made hereunder with respect to information/specification or the products to which information refers and no guarantee with respect to compliance to the intended use is given. In particular, this also applies to the stated possible applications or areas of applications of the product.

iC-Haus conveys no patent, copyright, mask work right or other trade mark right to this product. iC-Haus assumes no liability for any patent and/or other trade mark rights of a third party resulting from processing or handling of the product and/or any other use of the product.



Rev B2, Page 10/10

ORDERING INFORMATION

Туре	Package	Order Designation
iC-MHA	QFN28	iC-MHA QFN28-5x5

For technical support, information about prices and terms of delivery please contact:

iC-Haus GmbH Am Kuemmerling 18 D-55294 Bodenheim GERMANY Tel.: +49 (0) 61 35-92 92-0 Fax: +49 (0) 61 35-92 92-192 Web: http://www.ichaus.com E-Mail: sales@ichaus.com

Appointed local distributors: http://www.ichaus.com/sales_partners